








<p>1 You need: Siderise Foil Tape RFT120/45 and 40mm spiral screws.</p>	<p>2 Cutting on site – tools required: marker, tape measure, knife and saw.</p>	<p>3 Cutting on site – measure the cover area size and mark on the foil facing your cut line.</p>	<p>4 Cutting on site – Use a sharp knife to cut through the foil and net facings.</p>	<p>5 Cutting on site – Cut the stonewool with a saw, being careful not to rip the facings.</p>
				
<p>6 Measure the height and width of the balcony bracket. Cut a piece the same width & two side pieces the same height plus the thickness of the board so that the sides overlap the base. Boards must be cut to span cavity and form a tight fit between inner and outer substrates.</p>	<p>7 Using spiral screws, assemble the three pieces to fit around the balcony bracket. A minimum of 2 screws per joint, maximum of 100mm centres. 25mm boards must be used for these pieces, net facings inwards.</p>	<p>8 Using Siderise RFT 120/45 Foil Tape, apply tape to the joints covering the edges and screw heads. Foil tape is not required on the front faces.</p>	<p>9 Measure the size of the outer perimeter including the previously formed pieces. Cut a piece for the top and the bottom and two sides. The side pieces should overlap the top and bottom.</p>	<p>10 Assemble the pieces using spiral screws, minimum 2 per joint and maximum 100mm centres. Top board minimum thickness of 15mm, rest of boards minimum thickness of 25mm.</p>
		<p>SCAN / CLICK HERE FOR</p>  <p>FURTHER INSTRUCTIONS</p>		
<p>11 Using Siderise RFT 120/45 Foil Tape, apply tape to all joints ensuring to cover edges and screw heads. Foil tape is not required on the front faces.</p>	<p>12 The cavity barriers/firestops can now be installed to the BB-FB. the joint must be tight with no gaps and Siderise RFT 120/45 Foil Tape is applied to the joint on the top side. For some masonry applications a DPC may be required on the front face of the BB-FB, see datasheet or contact Technical Services.</p>			