

# Siderise CT Cavity Tray DPM Seal

Durable damp proof membrane with high performance adhesive backing.



## Application

Siderise CT Cavity Tray DPM Seal is a PVC film coated with an aggressive, cross-linked solvent based rubber-resin adhesive. The tape is flexible, allowing it to conform to different shapes and angles.

Siderise CT Cavity Tray DPM Seal is available for use with Siderise CT Cavity Tray at internal and external corners where the tray meets the outer brickwork leaf. It is also used when dealing with returns and stop ends where the Cavity Tray may come into contact with mortar.

See Siderise CT Cavity Tray Installation Instructions for further information.

## Technical Specification

**Table 1: Product Properties**

| Properties  | Value   |
|---|---|
| Thickness (mm)  | 0.19  |
| Length (m)  | 33  |
| Width (mm)  | 120   |
| Breaking Load (N/cm)                                    | 30 N/cm   |
| Elongation (%)  | 250%  |
| Adhesion Steel (N/cm)                                   | 2.6 N/cm  |
| Adhesion Self (N/cm)                                    | 2.5 N/cm  |
| Moisture Vapour Permeability (g/m <sup>2</sup> /24 hrs) | 40g/m <sup>2</sup> /24 hrs  |
| RoHS Compliant  | Yes   |
| Service Temperature (oC)                                | -18oC to +80oC  |
| Application Temperature (oC)                            | -10oC to +80oC  |
| Storage Temperature (oC)                                | +12oC to 25oC (tapes stored below the minimum recommended temperature will require warming up to that level before use) |

Please contact our customer service team: [customer.service@siderise.com](mailto:customer.service@siderise.com) for more information.

## Technical Support

For technical advice or support please contact: [technical.services@siderise.com](mailto:technical.services@siderise.com)

For Installation Training or Site Inspections please contact: [site.services@siderise.com](mailto:site.services@siderise.com)

## Context

The information in this datasheet is believed to be accurate at the date of publication. Siderise has a policy of continuous product improvement and reserves the right to alter or amend the specifications of products without prior notice. Siderise does not accept responsibility for the consequences of using the products described outside of the recommendations within this datasheet. Expert advice should be sought where there is any doubt about the correct specification or installation of Siderise products.

Siderise CT Cavity Tray DPM Seal\_L1\_01\_20240708\_1326