















<p>1 You need: Siderise® Fixing Brackets, Siderise® 'RFT' Foil Tape, suitable non-combustible mechanical fixings appropriate to substrate, supplied by contractor.</p>	<p>2 Cutting on site – tools required: marker, tape measure, knife and saw.</p>	<p>3 Cutting on site – Measure and mark the sheet: size of the void plus 10mm compression.</p>	<p>4 Cutting on site – Cut in the direction that is marked on the foil face of the sheet.</p>	<p>5 Cutting on site – Use a sharp knife to cut through the foil facings on both sides.</p>
				
<p>6 Cutting on site – Cut the stone wool with a saw, being careful not to rip the foil facing.</p>	<p>7 Inserting Brackets – Impale fixing bracket mid thickness into the back of the cavity barrier. A sharp knife can be inserted first to make it easier. Brackets are impaled at nominal 600mm fixing centres, i.e. 300mm from each end.</p>	<p>8 Inserting Brackets – Using personal protection equipment (e.g. gloves) fold the bracket as shown.</p>	<p>9 Inserting Brackets – Maximum penetration of bracket is 75% of the width of the cut strip (e.g. if the cut strip is 100mm wide, bracket penetration is 75mm).</p>	<p>10 Installing 'RV' Vertical Barriers – Fix brackets to the wall at 600mm centres, using non-combustible fixings.</p>
				
<p>11 Installing 'RV' Vertical Barriers – Press the barrier onto brackets ensuring it is tightly abutted to the barrier below and above.</p>	<p>12 Installing 'RV' Vertical Barriers – Seal joints between abutting barriers with Siderise 'RFT' foil tape on both sides.</p>	<p>13 Installing 'CH' Horizontal Barriers – For the horizontal barrier insert the brackets into the 'CH' barrier then fix to the wall. This time the incisions must be in horizontal orientation.</p>	<p>14 Installing 'CH' Horizontal Barriers – Hold barrier against the wall. Make sure the barrier is tightly abutting the previous barrier or vertical barrier.</p>	<p>15 Installing 'CH' Horizontal Barriers – Fix the brackets to the wall using non-combustible fixings, ensuring the barrier is tightly abutted to the barriers next to it.</p>
				<p>SCAN / CLICK HERE FOR</p>  <p>SIDERISE integrity in all we do</p>
<p>16 Installing Barriers – Seal joints with Siderise 'RFT' foil tape on the top side.</p>	<p>17 Where 'CH' horizontal and 'RV' vertical barriers meet ensure that they are tightly abutted. Seal corners and junctions on the top side with Siderise 'RFT' foil tape.</p>	<p>18 External corners should be mitred. Carefully cut barriers to ensure mitred edges are tightly abutted, and then apply Siderise 'RFT' foil tape.</p>	<p>19 When installing around windows or doors every internal and external joint where 'RV' vertical and 'CH' horizontal barriers meet, must be sealed with Siderise 'RFT' foil tape.</p>	<p>FURTHER INSTRUCTIONS</p>