

|  |   |   |  |   |
|--|---|---|--|---|
|  |   |   |  |   |
| <p><b>1</b> You need: Siderise Foil Tape RFT120/45, Suitable non-combustible fixings with a washer 10-15mm in diameter and spiral screws supplied by contractor.</p> | <p><b>2</b> Cutting on site – tools required: marker, tape measure, knife and saw.</p>  | <p><b>3</b> Cutting on site – measure the cover area size and mark on the foil facing your cut line.</p>                                | <p><b>4</b> Cutting on site – Use a sharp knife to cut through the foil and net facings.</p>               | <p><b>5</b> Cutting on site – Cut the stonewool with a saw, being careful not to rip the foil facing.</p>   |
|  |   |   |  |   |
| <p><b>6</b> Line up the board against the back of the façade checking the full area is covered.</p>  | <p><b>7</b> Use non-combustible fixings with a washer 10-15mm in diameter to fix the board to the façade; 6-7 number per m<sup>2</sup>.</p> | <p><b>8</b> Line up the next board tightly abutting the previous and fix to the façade.</p>   | <p><b>9</b> Using Siderise Foil Tape RFT120/45, tape the abutting joints between boards.</p>               | <p><b>10</b> Using Siderise Foil Tape RFT120/45, tape any exposed screw heads and washers.</p>  |
|  |   |   |  | <p><b>ALTERNATIVE INSTALLATION METHOD AVAILABLE</b></p> <p>SCAN / CLICK HERE FOR</p> <p><b>SIDERISE</b><br/>integrity in all we do</p> <p><b>FURTHER INSTRUCTIONS</b></p> |
| <p><b>11</b> Siderise Firestop can now be installed between the structure and the protected spandrel.</p>  | <p><b>12</b> Installing Barrier – Take the CW-FS unit and apply manual compression to install it into the cavity.</p>                       | <p><b>13</b> Fix the CW-FB covering the back of the mullion and overlapping the first board under the firestop using spiral screws.</p> | <p><b>14</b> Using Siderise Foil Tape RFT120/45, tape the spiral screws and edges to the first boards.</p> |   |